

To find the model on your Android device go to Settings > About phone or About tablet.

Babolat PLAY is compatible with most devices equipped with Bluetooth and running Android 4.0.3 or later.

Babolat has verified compatibility with all major Android devices. Non listed devices have not been verified but might be compatible as well.

If you need more information on whether your device can use Babolat PLAY, please feel free to contact our customer service.

Brand	Model	OS Required	Compatibility
Aquos	Serie	Android 4.0.3+	✓
Aquos	Zeta	Android 4.0.3+	✓
Arrows	NX	Android 4.0.3+	✓
Asus	Nexus 7	Android 4.0.3+	✓
Asus	Zenfone 2	Android 4.0.3+	✓
HTC	J Butterfly	Android 4.0.3+	✓
HTC	Nexus 9	Android 4.0.3+	✓
HTC	One M7	Android 4.0.3+	✓
HTC	One M8	Android 4.0.3+	✓
HTC	One M9	Android 4.0.3+	✓
Isai	Vivid	Android 4.0.3+	✓
LG	Disney Mobile	Android 4.0.3+	✓
LG	Nexus 4	Android 4.0.3+	✓
LG	Nexus 5	Android 4.0.3+	✓

Brand	Model	OS Required	Compatibility
Motorola	Moto E	Android 4.0.3+	✓
Motorola	Moto G	Android 4.0.3+	✓
Motorola	Moto X	Android 4.0.3+	✓
Motorola	Nexus 6	Android 4.0.3+	✓
OnePlus	One	Android 4.0.3+	✓
Samsung	Galaxy A5	Android 4.0.3+	✓
Samsung	Galaxy A7	Android 4.0.3+	✓
Samsung	Galaxy Alpha	Android 4.0.3+	✓
Samsung	Galaxy Note 4	Android 4.0.3+	✓
Samsung	Galaxy S3 mini	Android 4.0.3+	✓
Samsung	Galaxy S4	Android 4.0.3+	✓
Samsung	Galaxy S4 mini	Android 4.0.3+	✓
Samsung	Galaxy S5	Android 4.0.3+	✓
Samsung	Galaxy S5 mini	Android 4.0.3+	✓

Brand	Model	OS Required	Compatibility
Samsung	Galaxy S6	Android 4.0.3+	✓
Samsung	Galaxy S6 Edge	Android 4.0.3+	✓
Sony	Xperia Z1 Compact	Android 4.0.3+	✓
Sony	Xperia Z3	Android 4.0.3+	✓
Sony	Xperia Z3	Android 4.0.3+	✓
Sony	Xperia Z4	Android 4.0.3+	✓
VAIO	Phone	Android 4.0.3+	✓

Last updated: 10/11/2015